

RC5 output codes for the Meridian MSR.4 handset.

The following table shows the RC5 codes generated by the MSR.4 when used in 500 series mode. Keys in common with the original MSR produce the same RC5 output. The system code used in every case is 19.

Key	System code : Command code
CD	19:107
Radio	19:108
LP	19:114
TV	19:115
Tape 1	19:109
Tape 2	19:110
CDR	19:117
DVD	19:111
Text	19:116
VCR 1	19:112
VCR 2	19:113
Laser Disc	19:76
1	19:1
2	19:2
3	19:3
Previous	19:33
Play	19:53
Next	19:32
Pause	19:48
Repeat	19:29
Off	19:12
4	19:4
5	19:5
6	19:6
<<	19:50
Stop	19:54
>>	19:52
Subtitle (on/off)	19:40
Store	19:46
Volume up	19:16
7	19:7
8	19:8
9	19:9
Return	19:83
Menu up	19:80
Enter	19:87
Menu	19:82
Clear	19:49
Volume down	19:17
0	19:0
Top menu	19:121
Menu left	19:85
Menu down	19:81
Menu right	19:86
DSP	19:93
Display	19:122
Mute	19:13

The shifted keys are:

Key	Function	
Play	Audio	19:35
Pause	Record	19:55
Repeat	A-B Repeat	19:59
Off	Phase	19:60
Stop	Open	19:45
>>	Next page/slow	19:10
<<	Previous page	19:68
Subtitle	Subtitle language	19:42
Previous	Angle	19:58
Next	OSD	19:51
Menu	Setup	19:69
Top menu	# button	19:67
DSP	Band	19:14
Volume up	Secondary volume up	19:102
Volume down	Secondary volume down	19:103
Menu up	Secondary menu up	19:94
Menu down	Secondary menu down	19:95
Menu left	Secondary menu left	19:96
Menu right	Secondary menu right	19:97
Clear	Secondary clear	19:47
Store	Secondary store	19:41
Display	Secondary display	19:11
Mute	Secondary mute	19:91