

568 Front panel controls.

V1.0 JMB 23/8/99.

The table below shows the features that are accessible from the front panel of the 568, while the unit is in standby.

Key	
Source	Press to turn unit on.
Store	Hold down to toggle diagnostic displays.
Preset	Hold down to toggle lock.
Mute	Hold down to toggle Sine/sub mode.
Display	Press to view version and owner information.
Down	Hold down to toggle Metric/Imperial measurement.
Up	Hold down to start type process.
Off	Hold down to enter calibrate mode.